






Elite Replacement Part Instructions



Warning: Turn off the machine before performing any repairs or installations.

Step #	Description	Tools	Picture
1	Open the Control Panel by removing the four screws, one in each corner.	Phillips Screw Driver	
2	Gently pull the Control Panel out and allow it to rest below the opening.		
3	Clean the right side of the ball chute with a damp cloth, using either warm water or rubbing alcohol. Ensure the area is dried prior to installing the remote.		
4	Remove the protective backing from the adhesive side of the Velcro strip and place the remote on the right side of the ball chute with the antenna wire facing forward and the connector to the rear. Press the remote firmly on the ball chute.		
5	Attach the wire harness connector to the electronics board in the pins labeled J22 remote.		
6	Ensure that all wires are connected and reinstall Control Panel with 4 screws.	Phillips Screwdriver	
7	Test the functions of the machine including, power switch, elevation, sweep, and feed.		
9	Turn the remote switch to "ON". Test the feed and sweep functions using the Key Fob.		
10	If there are any problems, the first step is to ensure that all the wires are connected to the electronic board.		

Formatted: Font: (Default) Arial